

Multi Sport Net Assembly

IMPORTANT: Please read directions thoroughly before assembling your Multi-Sport Net.

1. Take all parts out of the box.
2. Lay out the net, with the solid material floor of the net, on the ground, and stretch the four corners into position (see Figure 1).
3. Assemble the 2 shock corded poles to their fullest length.
4. Find the solid material pole sleeve on the upper half of the net and insert the assembled shock-corded poles diagonally by pushing them through the pole sleeves (Figure 1). Insert the first pole at corner A1 and push through to corner A2. This procedure is basically the same as putting up a tent. Insert the second pole at corner B1 and put through corner B2.
5. Attach one end of the shock-cord pole into the pole attachment at corner A1 as per Figure 2. At the opposite end, flex pole and attach, to the pole attachment at corner A2. Make sure the poles slide freely in the pole sleeves. Repeat with other pole at B1 and B2.
6. Spread the four corners until the net floor is taut. Use the stakes to secure the net to the ground. Secure the stakes through the corner rings located at each corner of the floor.
7. Attach the clips and tie the ties, located on the net, to the poles for extra stability. The clips and ties are located on the net as per "C" on Figure 1.
8. Attach the target by attaching the ties to the "D" rings located at the ends of the rear center seam and at the bottom rear corners.



Figure 1




Figure 2

